

PACIFIC POLYMERS ®**“General Guidelines-Spraying Elasto-Deck BT”**

- Spray equipment should be a 45:1 ratio pump.
- Operate at 90 to 100 PSI with a 70 cfm air supply.
- Use a .045” tip in a reverse-A-Clean nozzle.
- Use a 1” diameter material hose up to 150’ long and a 6’ long, 3/8”-1/2”
- Diameter whips hose.
- For large jobs, it may be necessary to use a 1:1 Transfer Pump to avoid surging.

Note: These are general guidelines, field conditions, equipment, temperature etc. may affect product application.

Please consult the product data sheets, SDS’s and your sales representative for specific project applications.

**Acryl-R®****Permathane®****ITW Polymers Sealants North America**

111 S. Nursery Road. Irving, TX

Tel 1-800-878-7876

International 972-438-9111

Fax 972-554-3939

www.itwpsna.com